



Asus ZenWatch 2 Watch Strap Replacement

A repair guide showing how to replace a wrist strap on the Asus ZenWatch 2.

Written By: Moriah



INTRODUCTION

The Asus ZenWatch 2 comes equipped with two detachable leather straps. Straps are available in two sizes and new straps can be purchased in a variety of colors, patterns, and premium materials. Replacing the straps is a simple process found in the guide below.

Step 1 — Watch Strap



- Locate the sliding knobs on the underside of the watch.

Step 2



- Slide the knob inward.

Step 3



- Pull up at an angle to detach the strap from the faceplate.
- Repeat for the other side as well.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 08:49:41 PM.